




Installation manual

Packaged air-cooled water chillers and packaged air to water heat pumps



EWAQ004BAVP
EWAQ005BAVP

EWYQ004BAVP
EWYQ005BAVP

Installation manual
Packaged air-cooled water chillers and packaged air to water heat
pumps

English

Table of Contents

1	About the documentation	3
1.1	About this document.....	3
2	About the box	4
2.1	Outdoor unit.....	4
2.1.1	To remove the accessories from the outdoor unit.....	4
3	Preparation	4
3.1	Preparing the installation site.....	4
3.1.1	Installation site requirements of the outdoor unit.....	4
3.2	Preparing water piping.....	4
3.2.1	To check the water volume and flow rate.....	4
3.3	Preparing electrical wiring.....	5
3.3.1	Overview of electrical connections for external and internal actuators.....	5
4	Installation	5
4.1	Opening the units.....	5
4.1.1	To open the outdoor unit.....	5
4.1.2	To open the switch box cover of the outdoor unit.....	5
4.2	Mounting the outdoor unit.....	5
4.2.1	To provide the installation structure.....	5
4.2.2	To install the outdoor unit.....	6
4.2.3	To provide drainage.....	7
4.2.4	To prevent the outdoor unit from falling over.....	7
4.3	Connecting the water piping.....	8
4.3.1	To connect the water piping.....	8
4.3.2	To protect the water circuit against freezing.....	8
4.3.3	To fill the water circuit.....	9
4.3.4	To insulate the water piping.....	9
4.4	Connecting the electrical wiring.....	10
4.4.1	To connect the electrical wiring on the outdoor unit.....	10
4.4.2	To connect the main power supply.....	10
4.4.3	To connect the user interface.....	10
4.4.4	To connect the shut-off valve.....	11
5	Configuration	11
5.1	Overview: Configuration.....	11
5.1.1	To access the most used commands.....	12
5.2	Basic configuration.....	12
5.2.1	Quick wizard: Language / time and date.....	12
5.2.2	Quick wizard: Standard.....	13
5.2.3	Quick wizard: Options.....	13
5.2.4	Quick wizard: Capacities (energy metering).....	14
5.2.5	Space heating/cooling control.....	14
5.2.6	Contact/helpdesk number.....	15
5.3	Advanced configuration/optimization.....	15
5.3.1	Space heating/cooling operation: advanced.....	15
5.4	Menu structure: Overview installer settings.....	16
6	Commissioning	17
6.1	Checklist before commissioning.....	17
6.2	Checklist during commissioning.....	17
6.2.1	To perform an air purge.....	17
6.2.2	To perform a test run.....	18
6.2.3	To perform an actuator test run.....	18
6.2.4	To perform an underfloor heating screed dryout.....	18
7	Hand-over to the user	18
7.1	About locking and unlocking.....	19
	To activate or deactivate a function lock.....	19
	To activate or deactivate button lock.....	19
8	Technical data	20
8.1	Piping diagram: Outdoor unit.....	20
8.2	Wiring diagram: Outdoor unit.....	21

1 About the documentation

1.1 About this document

Target audience

Authorised installers



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you must read before installing
 - Format: Paper (in the box of the outdoor unit)
- **Outdoor unit installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the outdoor unit)
- **Control box installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the control box)
- **Option box installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the option box)
- **Backup heater installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the backup heater)
- **Installer reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>
- **Addendum book for optional equipment:**
 - Additional info about how to install optional equipment
 - Format: Paper (in the box of the outdoor unit) + Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>
- **Instruction sheet for valve kit EKMBHBP1:**
 - Instructions for the integration of valve kit EKMBHBP1
 - Format: Paper (in the box of the outdoor unit)



INFORMATION: ABOUT THE CONTROL BOX, OPTION BOX, AND BACKUP HEATER INSTALLATION MANUALS

EWAQ004+005BAVP and EWYQ004+005BAVP systems do NOT support domestic hot water and heat pump convector functionalities. In the installation manual of the control box, option box, and backup heater, therefore any reference to "domestic hot water", "domestic hot water tank", "booster heater", and "heat pump convector", may be disregarded.

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

2 About the box

Technical engineering data


- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

2 About the box


2.1 Outdoor unit

2.1.1 To remove the accessories from the outdoor unit

- Open the outdoor unit.



- Remove the accessories.



- a General safety precautions
- b Addendum book for optional equipment
- c Outdoor unit installation manual
- d Operation manual
- e Instruction sheet for valve kit EKMBHBP1
- f Sealing ring for shut-off valve
- g Shut-off valve
- h Unit mounting plate
- i User interface
- j Energy label



INFORMATION


The instruction sheet for valve kit EKMBHBP1 only applies in case valve kit EKMBHBP1 is part of the system. If so, do NOT take into account the instruction sheet delivered with the valve kit; it is overruled by the one delivered with the outdoor unit.

3 Preparation

3.1 Preparing the installation site

3.1.1 Installation site requirements of the outdoor unit

Mind the following spacing guidelines:



INFORMATION

If shut-off valves are installed on the unit, provide a minimum space of 400 mm at the air inlet side. If shut-off valves are NOT installed on the unit, provide a minimum space of 250 mm.

Do NOT install the unit in sound sensitive areas (e.g. near a bedroom), so that the operation noise will cause no trouble.

Note: If the sound is measured under actual installation conditions, the measured value might be higher than the sound pressure level mentioned in "Sound spectrum" in the data book due to environmental noise and sound reflections.



INFORMATION

The sound pressure level is less than 70 dBA.

The outdoor unit is designed for outdoor installation only, and for ambient temperatures ranging 10~43°C in cooling mode and – 20~25°C in heating mode.

3.2 Preparing water piping

3.2.1 To check the water volume and flow rate

Minimum water volume

If	Then
The system contains a backup heater	The minimum water volume is 10 l ^(a)
The system does NOT contain a backup heater	The minimum water volume is 20 l ^(a)

(a) The internal water volume of the outdoor unit NOT included.



NOTICE

When circulation in each space heating/cooling loop is controlled by remotely controlled valves, it is important that the minimum water volume is guaranteed, even if all of the valves are closed.

Minimum flow rate

Check that the minimum flow rate (required during defrost/backup heater operation) in the installation is guaranteed in all conditions.

**NOTICE**

If glycol was added to the water circuit, and the temperature of the water circuit is low, the flow rate will NOT be displayed on the user interface. In this case, the minimum flow rate can be checked by way of the pump test (check that the user interface does NOT display error 7H).

**NOTICE**

When circulation in each or certain space heating loops is controlled by remotely controlled valves, it is important that the minimum flow rate is guaranteed, even if all valves are closed. In case the minimum flow rate cannot be reached, a flow error 7H will be generated (no heating or operation).

See the installer reference guide for more information.

Minimum required flow rate	
04+05 models	12 l/min

See the recommended procedure as described in "6.2 Checklist during commissioning" on page 17.

3.3 Preparing electrical wiring**3.3.1 Overview of electrical connections for external and internal actuators**

Item	Description	Wires	Maximum running current
Outdoor unit power supply			
1	Power supply for outdoor unit	2+GND	(a)
2	Normal kWh rate power supply	2	6.3 A
User interface			
3	User interface	2	(b)
Optional equipment			
4	Remote outdoor sensor	2	(c)
Field-supplied components			
5	Space heating/cooling operation control (or shut-off valve)	2	(e)
Interconnection cable			
6	Interconnection cable between outdoor unit and control box	2	(d)

- (a) Refer to name plate on outdoor unit.
 (b) Cable section 0.75 mm² till 1.25 mm²; maximum length: 500 m. Applicable for both single user interface and dual user interface connection.
 (c) Minimum cable section 0.75 mm².
 (d) Cable section 0.75 mm² till 1.25 mm²; maximum length: 20 m.
 (e) If valve kit EKMBHBP1 is part of the system, then the required cable section is 0.75 mm². If valve kit EKMBHBP1 is NOT part of the system, then the minimum required cable section is 0.75 mm².

**NOTICE**

More technical specifications of the different connections are indicated on the inside of the outdoor unit.

**INFORMATION**

From the control box installation manual (same chapter), disregard the following items:



- 9 – 3-way valve
- 10 – Power supply for booster heater and thermal protection (from control box)
- 11 – Power supply for booster heater (to control box)
- 12 – Domestic hot water tank thermistor
- 13 – Heat pump convector

4 Installation**4.1 Opening the units****4.1.1 To open the outdoor unit**

DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING

**4.1.2 To open the switch box cover of the outdoor unit****4.2 Mounting the outdoor unit****4.2.1 To provide the installation structure****INFORMATION**

For information on the available options, contact your dealer.


If the unit is installed directly on the floor, prepare 4 sets of M8 or M10 anchor bolts, nuts and washers (field supply) as follows:

4 Installation




INFORMATION



The maximum height of the upper protruding part of the bolts is 15 mm.



In any case, provide at least 300 mm of free space below the unit. Additionally, make sure the unit is positioned at least 100 mm above the maximum expected level of snow.



It is possible to install the unit on brackets to the wall:




4.2.2 To install the outdoor unit




CAUTION

Do NOT remove the protective cardboard before the unit is installed properly.

1 Lift the outdoor unit.



2 Install the outdoor unit as follows:




a Air outlet



NOTICE

Properly align the unit. Make sure the backside of the unit does NOT protrude.

3 Remove the protective cardboard and instruction sheet.




a Protective cardboard
b Instruction sheet



NOTICE

To prevent damage to the supporting feet, do NOT tilt the unit sideways in any way:



4.2.3 To provide drainage

Make sure that condensate can be evacuated properly. When the unit is in cooling mode, condensate may also form in the hydro part. When providing drainage, therefore make sure to cover the entire unit.



NOTICE

If the unit is installed in a cold climate, take adequate measures so that the evacuated condensate CANNOT freeze.



INFORMATION

For information on the available options, contact your dealer.



NOTICE


Provide at least 300 mm of free space below the unit. Additionally, make sure the unit is positioned at least 100 mm above the expected level of snow.

4.2.4 To prevent the outdoor unit from falling over

In case the unit is installed in places where strong wind can tilt the unit, take following measure:

- 1 Prepare 2 cables as indicated in the following illustration (field supply).
- 2 Place the 2 cables over the outdoor unit.
- 3 Insert a rubber sheet between the cables and the outdoor unit to prevent the cables from scratching the paint (field supply).
- 4 Attach the ends of the cables and tighten them.

4 Installation



4.3 Connecting the water piping


4.3.1 To connect the water piping



NOTICE

Do NOT use excessive force when connecting the piping. Deformation of the piping can cause malfunctioning of the unit. Make sure that the tightening torque does NOT exceed 30 N•m.

To facilitate service and maintenance, 2 shut-off valves are provided. Mount the valves on the space heating water inlet and space heating water outlet. Mind their position: the integrated drain valves will only drain the side of the circuit on which they are located. To be able to only drain the unit, make sure the drain valves are positioned between the shut-off valves and the unit.



a Water inlet
b Water outlet

- 1 Screw the outdoor unit nuts on the shut-off valves.
- 2 Connect the field piping on the shut-off valves.



NOTICE

Install a manometer in the system.



NOTICE

Install air purge valves at all local high points.

4.3.2 To protect the water circuit against freezing

Frost can damage the system. For this reason, if negative ambient temperatures are expected, make sure the water circuit is sufficiently protected against freezing. Freeze protection is model-dependent. Either add glycol to the water circuit, or provide the outdoor field piping with heater tape, according to the table below.

If then
Standard model (no -H- in the model name)	Add glycol to the water circuit, according to the instructions below. In this way, you protect the internal water piping, as well as the outdoor field piping.
Heater tape model (-H- in the model name)	The internal water piping is factory-equipped with heater tape and additional insulation, this to prevent it from freezing. To prevent the outdoor field piping from freezing, provide it with sufficient insulation or heater tape (field supply), according to the instructions below.

Heater tape (field supply)

- 1 Install heater tape to the outdoor field piping.
- 2 Provide external power supply for the heater tape.



NOTICE

- For the internal heater tape to operate, the power to the unit MUST be ON. For this reason, during cold periods, never disconnect the power, nor turn off the main switch.
- In case of a power failure, power to the heater tape (both internal and external) will be aborted and the water circuit will NOT be protected. To guarantee a full protection, it is always possible to add glycol to the water circuit, even when installing heater tape to the outdoor field piping.

Glycol

The required concentration of glycol depends on the lowest expected outdoor temperature, and on whether you want to protect the system from bursting or from freezing. To prevent the system from freezing, more glycol is required. Add glycol according to the table below.



INFORMATION

- Protection against bursting: the glycol will prevent the piping from bursting, but NOT the liquid inside the piping from freezing.
- Protection against freezing: the glycol will prevent the liquid inside the piping from freezing.

Lowest expected outdoor temperature	Prevent from bursting	Prevent from freezing
-5°C	10%	15%
-10°C	15%	25%
-15°C	20%	35%



NOTICE

- It is the responsibility of the installer to add the correct glycol percentage, depending on the expected ambient temperatures.
- The addition of glycol applies to BOTH cooling-only models (EWAQ004+005BAVP) AND reversible models (EWYQ004+005BAVP), and is independent of cooling or heating operation.
- The required concentration might differ depending on the type of glycol. ALWAYS compare the requirements from the table above with the specifications provided by the glycol manufacturer. If necessary, meet the requirements set by the glycol manufacturer.
- The added concentration of glycol should NEVER exceed 35%.
- If the liquid in the system is frozen, the pump will NOT be able to start. Mind that if you only prevent the system from bursting, the liquid inside might still freeze.
- In case of a power supply failure or pump failure, and NO glycol was added to the system, drain the system.
- When water is at standstill inside the system, the system is very likely to freeze and get damaged.

The following types of glycol are allowed:

- Ethylene glycol;**
- Propylene glycol**, including the necessary inhibitors, classified as Category III according to EN1717.



WARNING

Ethylene glycol is toxic.



NOTICE

Glycol absorbs water from its environment. Therefore do NOT add glycol that has been exposed to air. Leaving the cap off the glycol container causes the concentration of water to increase. The glycol concentration is then lower than assumed. As a result, the hydraulic components might freeze up after all. Take preventive actions to ensure a minimal exposure of the glycol to air.



NOTICE

- If overpressure occurs, the system will release some of the liquid through the pressure relief valve. If glycol was added to the system, take adequate measures so as to safely recover it.
- In any case, make sure that the flexible hose of the pressure relief valve is ALWAYS free to release pressure. Prevent water from staying and/or freezing up inside the hose.



WARNING


Due to presence of glycol, corrosion of the system is possible. Uninhibited glycol will turn acidic under the influence of oxygen. This process is accelerated by the presence of copper and high temperatures. The acidic uninhibited glycol attacks metal surfaces and forms galvanic corrosion cells that cause severe damage to the system. Therefore it is important that:

- the water treatment is correctly executed by a qualified water specialist,
- a glycol with corrosion inhibitors is selected to counteract acids formed by the oxidation of glycols,
- no automotive glycol is used because their corrosion inhibitors have a limited lifetime and contain silicates which can foul or plug the system,
- galvanized pipes are NOT used in glycol systems since the presence may lead to the precipitation of certain components in the glycol's corrosion inhibitor.

Adding glycol to the water circuit reduces the maximum allowed water volume of the system. For more information, refer to the chapter "To check the water volume and flow rate" in the installer reference guide.

4.3.3 To fill the water circuit

- 1 Connect the water supply hose to the drain and fill valve.



- 2 Open the drain and fill valve.
- 3 If an automatic air purge valve was installed, make sure it is open.
- 4 Fill the circuit with water until the manometer (field supply) indicates a pressure of ± 2.0 bar.
- 5 Purge as much air as possible from the water circuit. For instructions, see ["6 Commissioning" on page 17](#).
- 6 Refill the circuit until the pressure is ± 2.0 bar.
- 7 Repeat steps 5 and 6 until no more air is purged and there are no more pressure drops.
- 8 Close the drain and fill valve.
- 9 Disconnect the water supply hose from the drain and fill valve.

4.3.4 To insulate the water piping

The piping in the complete water circuit MUST be insulated to prevent condensation during cooling operation and reduction of the heating and cooling capacity.

To prevent the freezing of the outdoor water piping during winter time, the thickness of the sealing material MUST be at least 13 mm (with $\lambda=0.039$ W/mK).

4 Installation

If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

During winter, protect the water piping and shut-off valves against freezing by adding heat tape (field supply). If the outdoor temperature can drop below -20°C and no heat tape is used, it is recommended to install the shut-off valves indoors.

4.4 Connecting the electrical wiring



DANGER: RISK OF ELECTROCUTION




WARNING

ALWAYS use multicore cable for power supply cables.

4.4.1 To connect the electrical wiring on the outdoor unit

- 1 Remove the switch box cover. See "4.1.1 To open the outdoor unit" on page 5.
- 2 Insert the wiring at the back of the unit:




NOTICE

The distance between the high voltage and low voltage cables should be at least 25 mm.

Routing	Possible cables (depends on the installed options)
a Low voltage	<ul style="list-style-type: none"> User interface Interconnection cable to control box EKCB07CAV3 Remote outdoor sensor (option)
b High voltage	<ul style="list-style-type: none"> Normal kWh rate power supply Preferential kWh rate power supply Shut-off valve (field supply) Space heat/cool operation control
c Main power supply	<ul style="list-style-type: none"> Main power supply

- 3 Inside the unit, route the wiring as follows:



- 4 Make sure that the cable does NOT come in contact with sharp edges or hot gas piping.
- 5 Install the switch box cover.



INFORMATION

When installing field supply or option cables, foresee sufficient cable length. This will make it possible to remove/reposition the switch box and gain access to other components during service.




CAUTION

Do NOT push or place redundant cable length in the unit.

4.4.2 To connect the main power supply

- 1 Connect the main power supply.



4.4.3 To connect the user interface





INFORMATION

- If control box EKCB07CAV3 is NOT part of the system, connect the user interface directly to the outdoor unit.
- If control box EKCB07CAV3 is part of the system, you can also connect the user interface to the control box. To do this, connect the user interface to control box terminals X2M/20+21, and then connect the control box to the outdoor unit by connecting X2M/20+21 to outdoor unit terminals X5M/1+2.




INFORMATION

For details on how to connect the user interface to the control box, refer to the installer reference guide or the installation manual of the control box.

#	Action
1	<p>Connect the user interface cable to the outdoor unit.</p>  <p>a Main user interface^(a) b Optional user interface</p>
2	<p>Insert a screwdriver into the slots underneath the user interface and carefully separate the faceplate from the wallplate.</p> <p>The PCB is mounted in the faceplate of the user interface. Be careful NOT to damage it.</p> 
3	Fix the wallplate of the user interface to the wall.
4	Connect as shown in 4A, 4B, 4C or 4D.
5	<p>Reinstall the faceplate onto the wallplate.</p> <p>Be careful NOT to pinch the wiring when attaching the frontplate to the unit.</p>

(a) The main user interface is required for operation. It is delivered with the unit as accessory.



a Notch this part for the wiring to pass through with nippers etc.

- Secure the wiring to the front part of the casing using the wiring retainer and clamp.


4.4.4 To connect the shut-off valve

- Connect the valve control cable to the appropriate terminals as shown in the illustration below.




NOTICE

Only connect NO (normal open) valves.



INFORMATION

By default, the shut-off valve is to be connected to the outdoor unit. However, if control box EKCB07CAV3 is present in the system, you can also connect it to the control box. To do this, connect outdoor unit terminals X3M/1+2 to control box terminals X8M/6+7, and then connect the shut-off valve to control box terminals X8M/6+7.



5 Configuration

5.1 Overview: Configuration

This chapter describes what you have to do and know to configure the system after it is installed.



NOTICE

The explanation about the configuration in this chapter gives you ONLY basic explanations. For more detailed explanation and background information, see the installer reference guide.

5 Configuration

Why

If you do NOT configure the system correctly, it might NOT work as expected. The configuration influences the following:

- The calculations of the software
- What you can see on and do with the user interface

How

You can configure the system via the user interface.

- **First time – Quick wizard.** When you turn ON the user interface for the first time (via the indoor unit), a quick wizard starts to help you configure the system.
- **Afterwards.** If necessary, you can make changes to the configuration afterwards.



INFORMATION

When the installer settings are changed, the user interface will request to confirm. When confirmed, the screen will shortly turn OFF and "busy" will be displayed for several seconds.

Accessing settings – Legend for tables

You can access the installer settings using two different methods. However, NOT all settings are accessible via both methods. If so, the corresponding table columns in this chapter are set to N/A (not applicable).

Method	Column in tables
Accessing settings via the breadcrumb in the menu structure .	#
Accessing settings via the code in the overview settings .	Code

See also:

- ["To access the installer settings" on page 12](#)
- ["5.4 Menu structure: Overview installer settings" on page 16](#)

5.1.1 To access the most used commands

To access the installer settings

- 1 Set the user permission level to Installer.
- 2 Go to [A]: > Installer settings.

To access the overview settings

- 1 Set the user permission level to Installer.
- 2 Go to [A.8]: > Installer settings > Overview settings.

To set the user permission level to Installer

- 1 Set the user permission level to Adv. end user.
- 2 Go to [6.4]: > Information > User permission level.
- 3 Press for more than 4 seconds.

Result: is displayed on the home pages.

- 4 If you do NOT press any button for more than 1 hour or press again for more than 4 seconds, the installer permission level switches back to End user.

To set the user permission level to Advanced end user

- 1 Go to the main menu or any of its submenus: .
- 2 Press for more than 4 seconds.

Result: The user permission level switches to Adv. end user. Additional information is displayed and "+" is added to the menu title. The user permission level will stay in Adv. end user until set otherwise.

To set the user permission level to End user

- 1 Press for more than 4 seconds.

Result: The user permission level switches to End user. The user interface will return to the default home screen.

To modify an overview setting

Example: Modify [1-01] from 15 to 20.

- 1 Go to [A.8]: > Installer settings > Overview settings.
- 2 Go to the corresponding screen of the first part of the setting by using the and button.



INFORMATION

An additional 0-digit is added to the first part of the setting when you access the codes in the overview settings.

Example: [1-01]: "1" will result in "01".

Overview settings				
01				
00	01	15	02	03
04	05	06	07	
08	09	0a	0b	
0c	0d	0e	0f	
OK Confirm Adjust Scroll				

- 3 Go to the corresponding second part of the setting by using the and button.

Overview settings				
01				
00	01	15	02	03
04	05	06	07	
08	09	0a	0b	
0c	0d	0e	0f	
OK Confirm Adjust Scroll				

Result: The value to be modified is now highlighted.

- 4 Modify the value by using the and button.

Overview settings				
01				
00	01	20	02	03
04	05	06	07	
08	09	0a	0b	
0c	0d	0e	0f	
OK Confirm Adjust Scroll				

- 5 Repeat previous steps if you have to modify other settings.
- 6 Push **OK** to confirm the modification of the parameter.
- 7 At installer settings menu, press **OK** to confirm the settings.

Installer settings	
The system will restart.	
OK	Cancel
OK Confirm Adjust	

Result: The system will restart.

5.2 Basic configuration

5.2.1 Quick wizard: Language / time and date

#	Code	Description
[A.1]	N/A	Language
[1]	N/A	Time and date

5.2.2 Quick wizard: Standard

Space heating/cooling settings

#	Code	Description
[A.2.1.7]	[C-07]	Unit temperature control: <ul style="list-style-type: none"> 0 (LWT control): Unit operation is decided based on the leaving water temperature. 1 (Ext RT control): Unit operation is decided by the external thermostat. 2 (RT control): Unit operation is decided based on the ambient temperature of the user interface.
[A.2.1.9]	[F-0D]	Pump operation: <ul style="list-style-type: none"> 0 (Continuous): Continuous pump operation, regardless of thermo ON or OFF condition. 1 (Sample): When thermo OFF condition occurs, the pump runs every 5 minutes and the water temperature is checked. If the water temperature is below target, unit operation can start. 2 (Request): Pump operation based on request. Example: Using a room thermostat and thermostat creates thermo ON/OFF condition.
[A.2.1.B]	N/A	Only if there are 2 user interfaces: User interface location: <ul style="list-style-type: none"> At unit In room
[A.2.1.C]	[E-0D]	Glycol present: <ul style="list-style-type: none"> 0 (No)(default) 1 (Yes)

5.2.3 Quick wizard: Options

Remote outdoor sensor

#	Code	Description
[A.2.2.B]	[C-08]	External sensor (outdoor): <ul style="list-style-type: none"> 0 (No): NOT installed. 1 (Outdoor sensor): Remote outdoor sensor, connected to the outdoor unit. 2 (Room sensor): Remote indoor sensor, connected to option box EK2CB07CAV3.

**INFORMATION**

You can only connect either the remote indoor sensor or the remote outdoor sensor.

Control box EKCB07CAV3

#	Code	Description
[A.2.2.E.1]	[E-03]	Backup heater steps: <ul style="list-style-type: none"> 0 (default) 1 2

#	Code	Description
[A.2.2.E.2]	[5-0D]	BUH type: <ul style="list-style-type: none"> 1 (1P,(1/1+2)): 6 kW 1~ 230 V (default) 4 (3PN,(1/2)): 6 kW 3N~ 400 V (*9W) 5 (3PN,(1/1+2)): 9 kW 3N~ 400 V (*9W)

The system allows for the connection of 2 types of backup heater kits:

- EKMBUHCA3V3: 1~ 230 V - 3 kW backup heater
- EKMBUHCA9W1: Unified backup heater

Backup heater EKMBUHCA3V3 can only be configured to be a 3V3 backup heater. Unified backup heater EKMBUHCA9W1 can be configured in 4 ways:

- 3V3: 1~ 230 V, 1 step of 3 kW
- 6V3: 1~ 230 V, 1st step = 3 kW, 2nd step = 3+3 kW
- 6W1: 3N~ 400 V, 1st step = 3 kW, 2nd step = 3+3 kW
- 9W1: 3N~ 400 V, 1st step = 3 kW, 2nd step = 3+6 kW

To configure the backup heater (both EKMBUHCA3V3 and EKMBUHCA9W1), combine settings [E-03] and [5-0D]:

Backup heater configuration	[E-03]	[5-0D]
3V3	1	1 (1P,(1/1+2))
6V3	2	1 (1P,(1/1+2))
6W1	2	4 (3PN,(1/2))
9W1	2	5 (3PN,(1/1+2))

#	Code	Description
[A.2.2.E.5]	[C-05]	External room thermostat for the main zone: <ul style="list-style-type: none"> 1 (Thermo ON/OFF): When the used external room thermostat can only send a thermo ON/OFF condition. No separation between heating or cooling demand. 2 (H/C request): When the used external room thermostat can send a separate heating/cooling thermo ON/OFF condition.

Option box EK2CB07CAV3

#	Code	Description
[A.2.2.F.1]	[C-02]	External backup heater source: <ul style="list-style-type: none"> 0 (default – read only)
[A.2.2.F.2]	[C-09]	Alarm output <ul style="list-style-type: none"> 0 (Normally open): The alarm output will be powered when an alarm occurs. 1 (Normally closed): The alarm output will NOT be powered when an alarm occurs. This installer setting allows for a distinction between the detection of an alarm, and the detection of a power failure. <p>See also table below (Alarm output logic).</p>

5 Configuration

#	Code	Description
[A.2.2.F.3]	[D-08]	Optional external kWh meter 1: <ul style="list-style-type: none"> 0 (No): NOT installed 1: Installed (0.1 pulse/kWh) 2: Installed (1 pulse/kWh) 3: Installed (10 pulse/kWh) 4: Installed (100 pulse/kWh) 5: Installed (1000 pulse/kWh)
[A.2.2.F.4]	[D-09]	Optional external kWh meter 2: <ul style="list-style-type: none"> 0 (No): NOT installed 1: Installed (0.1 pulse/kWh) 2: Installed (1 pulse/kWh) 3: Installed (10 pulse/kWh) 4: Installed (100 pulse/kWh) 5: Installed (1000 pulse/kWh)

#	Code	Description
[A.2.2.F.5]	[C-08]	External sensor (indoor): <ul style="list-style-type: none"> 0 (No): NOT installed. 1 (Outdoor sensor): Remote outdoor sensor, connected to the outdoor unit. 2 (Room sensor): Remote indoor sensor, connected to option box EK2CB07CAV3.



INFORMATION

You can only connect either the remote indoor sensor or the remote outdoor sensor.

#	Code	Description
[A.2.2.F.6]	[D-04]	PCC by digital inputs: <ul style="list-style-type: none"> 0 (No) 1 (Yes)

5.2.4 Quick wizard: Capacities (energy metering)

#	Code	Description
[A.2.3.2]	[6-03]	Backup heater capacity (step 1) [kW]
[A.2.3.3]	[6-04]	Backup heater capacity (step 2) [kW]

5.2.5 Space heating/cooling control

Leaving water temperature: Main zone

#	Code	Description
[A.3.1.1.1]	N/A	Set point mode: <ul style="list-style-type: none"> 0 (Fixed): Absolute 1 (Weather dep.): Weather-dependent 2 (Fixed/scheduled): Absolute + scheduled (only for leaving water temperature control) 3 (WD/scheduled): Weather-dependent + scheduled (only for leaving water temperature control)

#	Code	Description
[7.7.1.1]	[1-00] [1-01] [1-02] [1-03]	Weather-dependent curve (heating): <ul style="list-style-type: none"> T_t: Target leaving water temperature (main) T_a: Outdoor temperature
[7.7.1.2]	[1-06] [1-07] [1-08] [1-09]	Weather-dependent curve (cooling): <ul style="list-style-type: none"> T_t: Target leaving water temperature (main) T_a: Outdoor temperature

Leaving water temperature: Delta T source

#	Code	Description
[A.3.1.3.1]	[9-09]	Heating: required temperature difference between entering and leaving water. In case a minimum temperature difference is required for the good operation of the heat emitters in heating mode.
[A.3.1.3.2]	[9-0A]	Cooling: required temperature difference between entering and leaving water. In case a minimum temperature difference is required for the good operation of the heat emitters in cooling mode.


Leaving water temperature: Modulation

#	Code	Description
[A.3.1.1.5]	[8-05]	Leaving water temperature modulation: <ul style="list-style-type: none"> 0 (No): Disabled 1 (Yes): Enabled. The leaving water temperature is calculated according to the difference between desired and actual room temperature. This allows better matching of the heat pump capacity to actual required capacity and results in less start/stop cycles of the heat pump and more economic operation.

#	Code	Description
N/A	[8-06]	Leaving water temperature maximum modulation: 0°C~10°C (default: 3°C) Requires modulation to be enabled. This is the value by which the desired leaving water temperature is increased or lowered.

**INFORMATION**

When leaving water temperature modulation is enabled, the weather-dependent curve needs to be set to a higher position than [8-06] plus the minimum leaving water temperature setpoint required to reach a stable condition on the comfort setpoint for the room. To increase efficiency, modulation can lower the leaving water setpoint. By setting the weather-dependent curve to a higher position, it cannot drop below the minimum setpoint. Refer to the illustration below.



- a** Weather-dependent curve
b Minimum leaving water temperature setpoint required to reach a stable condition on the comfort setpoint for the room.

Leaving water temperature: Emitter type

#	Code	Description
[A.3.1.1.7]	[9-0B]	Reaction time of the system: <ul style="list-style-type: none"> 0: Quick. Example: Small water volume and fan coils. 1: Slow. Example: Large water volume, floor heating loops. Depending on the system water volume and the heat emitters type, the heat up or cool down of a space can take longer. This setting can compensate for a slow or a quick heating/cooling system by adjusting the unit capacity during the heat up/cool down cycle.

5.2.6 Contact/helpdesk number

#	Code	Description
[6.3.2]	N/A	Number that users can call in case of problems.

5.3 Advanced configuration/optimization**5.3.1 Space heating/cooling operation: advanced****Water pipe freeze prevention**


#	Code	Description
N/A	[4-04]	<ul style="list-style-type: none"> 0 (Intermittent pump operation): Protection enabled. 1 (Continuous pump operation): Protection enabled. 2 (No protection): Protection disabled.

**NOTICE**

If negative ambient temperatures are expected, do NOT disable this function.

5 Configuration

5.4 Menu structure: Overview installer settings



INFORMATION

Depending on the selected installer settings and unit type, settings will be visible/invisible.

6 Commissioning



NOTICE

NEVER operate the unit without thermistors and/or pressure sensors/switches. Burning of the compressor might result.

6.1 Checklist before commissioning

After the installation of the unit, first check the following items. Once all below checks are fulfilled, the unit MUST be closed, ONLY then can the unit be powered up.

Depending on the system layout, not all components may be available.

<input type="checkbox"/>	You read the complete installation instructions, as described in the installer reference guide .
<input type="checkbox"/>	The outdoor unit is properly mounted.
<input type="checkbox"/>	The control box is properly mounted.
<input type="checkbox"/>	The option box is properly mounted.
<input type="checkbox"/>	Only if you use the optional backup heater: The backup heater is properly mounted.
<input type="checkbox"/>	The following field wiring has been carried out according to the available documentation and the applicable legislation: <ul style="list-style-type: none"> Between the local supply panel and the outdoor unit Between the outdoor unit and the control box Between the control box and the option box Between the control box and the backup heater Between the local supply panel and the control box Between the local supply panel and the option box Between the outdoor unit and the valves Between the control box and the room thermostat
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the outdoor unit.
<input type="checkbox"/>	Only if you use the optional backup heater: Depending on the backup heater type, backup heater circuit breaker F1B (on the switch box of the backup heater) is turned ON.
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.
<input type="checkbox"/>	There are no water leaks inside the outdoor unit.
<input type="checkbox"/>	The shut-off valves are properly installed and fully open.
<input type="checkbox"/>	The pressure relief valve purges water when opened.
<input type="checkbox"/>	The minimum water volume is guaranteed in all conditions. See "To check the water volume" in "3.2 Preparing water piping" on page 4 .



The **water circuit** is properly protected against **freezing**, according to the instructions set out in To protect the water circuit against freezing.



If **glycol** was added to the system, confirm the correct glycol concentration, and check if glycol setting [E-0D]=1.



NOTICE

- Make sure glycol setting [E-0D] matches the liquid inside the water circuit (0=water only, 1=water+glycol). If the glycol setting is NOT set correctly, the liquid inside the piping can freeze.
- When glycol is added to the system, but the glycol concentration is lower than prescribed, the liquid inside the piping can still freeze.



INFORMATION

The software is equipped with an "installer-on-site" mode ([4-0E]), that disables automatic operation by the unit. At first installation, setting [4-0E] is by default set to "1", meaning automatic operation is disabled. All protective functions are then disabled. If the user interface home pages are off, the unit will NOT operate automatically. To enable automatic operation and the protective functions, set [4-0E] to "0".

36 hours after the first power-on, the unit will automatically set [4-0E] to "0", ending "installer-on-site" mode and enabling the protective functions. If – after first installation – the installer returns to the site, the installer has to set [4-0E] to "1" manually.

6.2 Checklist during commissioning

<input type="checkbox"/>	The minimum flow rate is guaranteed in all conditions. See "To check the water volume and flow rate" in "3.2 Preparing water piping" on page 4 .
<input type="checkbox"/>	To perform an air purge .
<input type="checkbox"/>	To perform a test run .
<input type="checkbox"/>	To perform an actuator test run .
<input type="checkbox"/>	Underfloor screed dryout function The underfloor screed dryout function is started (if necessary).

6.2.1 To perform an air purge

Prerequisite: Make sure that the leaving water temperature home page and room temperature home page are turned OFF.

- Go to [A.7.3]: > Installer settings > Commissioning > Air purge.
- Set the type.
- Select Start air purge and press **OK**.
- Select OK and press **OK**.



NOTICE

The outdoor unit is equipped with a manual air purge valve. The air purge procedure requires manual action.



NOTICE

When purging air with the manual air purge valve of the unit, collect any fluid that might leak out of the valve. If this fluid is NOT collected, it might drip on internal components and damage the unit.

7 Hand-over to the user



INFORMATION

- To purge air, use all air purge valves present in the system. This includes the manual air purge valve of the outdoor unit, as well as any field-supplied valves.
- If the system contains a backup heater, also use the air purge valve of the backup heater.
- If the system contains valve kit EKMBHBP1, it is required to – during the air purge – manually switch the position of the valve kit's 3-way valve by turning its knob, this to prevent air from remaining in the bypass. For more information, refer to the instruction sheet of the valve kit.

6.2.2 To perform a test run

Prerequisite: Make sure that the leaving water temperature home page and room temperature home page are turned OFF.

- 1 Set the user permission level to Installer. See ["To set the user permission level to Installer" on page 12](#).
- 2 Go to [A.7.1]: > Installer settings > Commissioning > Test run.
- 3 Select a test and press **OK**. **Example:** Heating.
- 4 Select OK and press **OK**.

Result: The test run starts. It stops automatically when done (±30 min). To stop it manually, press , select OK and press **OK**.



INFORMATION

When starting up the system in a cold climate, and NO backup heater kit was installed, it may be required to start up with a small water volume. To do this, gradually open the heat emitters. As a result, the water temperature will gradually rise. Monitor the inlet water temperature ([6.1.6] in the menu structure) and make sure it does NOT drop below 15°C.



INFORMATION

If 2 user interfaces are present, you can start a test run from both user interfaces.

- The user interface used to start the test run displays a status screen.
- The other user interface displays a "busy" screen. You cannot use the user interface as long as the "busy" screen is shown.

6.2.3 To perform an actuator test run

Prerequisite: Make sure that the leaving water temperature home page and room temperature home page are turned OFF.

- 1 Set the user permission level to Installer. See ["To set the user permission level to Installer" on page 12](#).
- 2 Make sure room temperature control and leaving water temperature control are turned OFF via the user interface.
- 3 Go to [A.7.4]: > Installer settings > Commissioning > Actuator test run.
- 4 Select an actuator and press **OK**. **Example:** Pump.
- 5 Select OK and press **OK**.

Result: The actuator test run starts. It automatically stops when finished. To stop it manually, press , select OK and press **OK**.

Possible actuator test runs

- Backup heater (step 1) test
- Backup heater (step 2) test
- Pump test



INFORMATION

Make sure that all air is purged before executing the test run. Also avoid disturbances in the water circuit during the test run.

- 2-way valve test
- Alarm output test
- Cooling/heating signal test
- Circulation pump test

6.2.4 To perform an underfloor heating screed dryout

Prerequisite: Make sure there is ONLY 1 user interface connected to your system to perform an underfloor heating screed dryout.

Prerequisite: Make sure that the leaving water temperature home page and room temperature home page are turned OFF.

- 1 Go to [A.7.2]: > Installer settings > Commissioning > UFH screed dryout.
- 2 Set a dryout program.
- 3 Select Start dryout and press **OK**.
- 4 Select OK and press **OK**.

Result: The underfloor heating screed dryout starts. It stops automatically when done. To stop it manually, press , select OK and press **OK**.



NOTICE

To perform an underfloor heating screed dryout, room frost protection needs to be disabled ([2-06]=0). By default, it is enabled ([2-06]=1). However, due to the "installer-on-site" mode (see "Checklist before commissioning"), room frost protection will be automatically disabled for 36 hours after the first power-on.

If the screed dryout still needs to be performed after the first 36 hours of power-on, manually disable room frost protection by setting [2-06] to "0", and KEEP it disabled until the screed dryout has finished. Ignoring this notice will result in cracking of the screed.



NOTICE

For the underfloor heating screed dryout to be able to start, make sure the following settings are met:

- [4-00]=1
- [C-02]=0
- [D-01]=0
- [4-08]=0
- [4-01]≠1

7 Hand-over to the user

Once the test run is finished and the unit operates properly, please make sure the following is clear for the user:

- Fill in the installer setting table (in the operation manual) with the actual settings.
- Make sure that the user has the printed documentation and ask him/her to keep it for future reference. Inform the user that he can find the complete documentation at the URL mentioned earlier in this manual.
- Explain the user how to properly operate the system and what to do in case of problems.
- Show the user what to do for the maintenance of the unit.

- Explain the user about energy saving tips as described in the operation manual.





7.1 About locking and unlocking

If required, it is possible to lock the buttons of the main user interface, making it impossible for the user to operate it. For the user to be able to change setpoint temperatures, the simplified user interface or an external room thermostat is then required.



You can use the following locking modes:

- Function lock: Locks a specific function to prevent people from changing its settings.
- Button lock: Locks all buttons to prevent users from changing settings.

To activate or deactivate a function lock

- 1 Press  to go to the menu structure.
- 2 Press  for more than 5 seconds.
- 3 Select a function and press .
- 4 Select Lock or Unlock, and press .


To activate or deactivate button lock

- 1 Press  to go to one of the home pages.
- 2 Press  for more than 5 seconds.

8 Technical data

A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible). The **full set** of latest technical data is available on the Daikin extranet (authentication required).

8.1 Piping diagram: Outdoor unit



- 1 Outlet
- 2 Inlet
- 3 Shut-off valve with drain/fill valve
- 4 Flow switch
- 5 Pump
- 6 Flow sensor
- 7 Air purge
- 8 Plate heat exchanger
- 9 Safety valve
- 10 Filter
- 11 Expansion vessel
- 12 R1T - Outlet water heat exchanger thermistor
- 13 R3T - Refrigerant liquid side thermistor
- 14 R4T - Inlet water thermistor
- 15 Gas stop valve with service port
- 16 Pressure sensor
- 17 4-way valve
- 18 High pressure switch
- 19 Muffler
- 20 Compressor
- 21 Accumulator
- 22 Heat exchanger
- 23 Propeller fan
- 24 Capillary tube 1
- 25 Capillary tube 2
- 26 Capillary tube 3
- 27 Capillary tube 4
- 28 Muffler with filter
- 29 Motor-operated valve
- 30 Liquid stop valve
- 31 R1T - Discharge pipe thermistor
- 32 R3T - Outdoor air temperature thermistor
- 33 R2T - Heat exchanger thermistor
- A Water side
- B Refrigerant side
- Field installed

— Refrigerant flow - cooling
 - - - Refrigerant flow - heating

8.2 Wiring diagram: Outdoor unit

See the internal wiring diagram supplied with the unit (on the inside of the outdoor unit switch box cover). The abbreviations used are listed below.

Outdoor unit: compressor module

C110~C112	Capacitor
DB1, DB2, DB401	Rectifier bridge
DC_N1, DC_N2	Connector
DC_P1, DC_P2	Connector
DCP1, DCP2,	Connector
DCM1, DCM2	Connector
DP1, DP2	Connector
E1, E2	Connector
E1H	Drain pan heater
FU1~FU5	Fuse
HL1, HL2, HL402	Connector
HN1, HN2, HN402	Connector
IPM1	Intelligent power module
L	Live
LED 1~LED 4	Indication lamps
LED A, LED B	Pilot lamp
M1C	Compressor motor
M1F	Fan motor
MR30, MR306, MR307, MR4	Magnetic relay
MRM10, MRM20	Magnetic relay
MR30_A, MR30_B	Connector
N	Neutral
PCB1	Printed circuit board (main)
PCB2	Printed circuit board (inverter)
PCB3	Printed circuit board (service)
Q1DI	Earth leakage circuit breaker
Q1L	Overload protector
R1T	Thermistor (discharge)
R2T	Thermistor (heat exchanger)
R3T	Thermistor (air)
S1NPH	Pressure sensor
S1PH	High pressure switch
S2~S503	Connector
SA1	Surge arrestor
SHEET METAL	Terminal strip on fixed plate
SW1, SW3	Push buttons
SW2, SW5	DIP switches
U	Connector
V	Connector
V2, V3, V401	Varistor
W	Connector
X11A, X12A	Connector
X1M, X2M	Terminal strip
Y1E	Electronic expansion valve coil
Y1R	Reversing solenoid valve coil
Z1C~Z4C	Ferrite core
⎓ ■ ■ ■ ⎓	Field wiring
□ □ □ □	Terminal strip

	Connector
	Terminal
	Protective earth
BLK	Black
BLU	Blue
BRN	Brown
GRN	Green
ORG	Orange
PPL	Purple
RED	Red
WHT	White
YLW	Yellow

Outdoor unit: hydro module

English	Translation
(1) Connection diagram	(1) Connection diagram
Compressor switch box	Compressor switch box
Control box	Control box
External outdoor ambient sensor option	External outdoor ambient sensor option
Hydro switch box supplied from compressor module	Hydro switch box supplied from compressor module
Hydro switch box	Hydro switch box
Indoor	Indoor
NO valve	Normal open valve
Normal kWh rate power supply	Normal kWh rate power supply
Only for normal power supply (standard)	Only for normal power supply (standard)
Only for preferential kWh rate power supply (compressor)	Only for preferential kWh rate power supply (compressor)
Outdoor	Outdoor
Preferential power supply	Preferential kWh rate power supply
Use normal kWh rate power supply for hydro switch box	Use normal kWh rate power supply for hydro switch box
(2) Hydro switch box layout	(2) Hydro switch box layout
(3) Notes	(3) Notes
X4M	Main terminal
-----	Earth wiring
15	Wire number 15
-----	Field supply
①	Several wiring possibilities
	Option
	Wiring depending on model
	Switch box
	PCB
(4) Legend	(4) Legend
A1P	Main PCB
A2P	Current loop PCB
Q*DI	# Earth leakage circuit breaker
R6T	* External outdoor ambient sensor option

8 Technical data

English	Translation
TR1	Power supply transformer
X*M	Terminal strip
X*Y	Connector
PCB3	Service PCB
M2S	# Shut-off valve

*: Optional
#: Field supply

Control box

English	Translation
(1) Connection diagram	(1) Connection diagram
BUH option	Backup heater option
Control box	Control box
Hydro switch box	Hydro switch box
NO valve	Normal open valve
Only for ext. sensor (floor or ambient)	Only for external sensor (floor or ambient)
Only for wired On/OFF thermostat	Only for wired On/OFF thermostat
Only for wireless On/OFF thermostat	Only for wireless On/OFF thermostat
Option box	Option box
Preferential kWh rate power supply contact: 5 V DC detection (voltage supplied by PCB)	Preferential kWh rate power supply contact: 5 V DC detection (voltage supplied by PCB)
(2) Notes	(2) Notes
X1M	Main terminal
-----	Earth wiring
15	Wire number 15
-----	Field supply
①	Several wiring possibilities
	Option
	Wiring depending on model
	Switch box
	PCB
(3) Control switch box layout	(3) Control switch box layout
(4) Legend	(4) Legend
A3P	* On/OFF thermostat (PC=power circuit)
A4P	* Extension PCB (control, optional)
A5P	User interface PCB
A7P	* Receiver PCB (wireless On/OFF thermostat)
M2S	# Shut-off valve
M4S	* Valve kit
Q*DI	# Earth leakage circuit breaker
R1T (A3P)	* Ambient sensor On/OFF thermostat
R2T (A3P)	* External sensor (floor or ambient)
S1S	# Preferential kWh rate power supply contact
X*M/K1	Terminal strip
X*Y	Connector
K1A	Relay for heating
K2A	Relay for cooling

*: Optional
#: Field supply





Control box option: backup heater

English	Translation
(1) Connection diagram	(1) Connection diagram
BUH option	Backup heater option
Control box	Control box
Only for ***	Only for ***
(2) Notes	(2) Notes
-----	Earth wiring
15	Wire number 15
-----	Field supply
①	Several wiring possibilities
	Option
	Wiring depending on model
	Switch box
	PCB
(3) BUH kit switch box	(3) BUH kit switch box
(4) Legend	(4) Legend
F1B	Overcurrent fuse backup heater
K1R	Relay backup heater (step 1)
K2R	Relay backup heater (step 2) (only for *9W)
K1M	Contactor backup heater (step 1)
K2M	Contactor backup heater (step 2) (only for *9W)
K5M	Safety contactor backup heater (only for *9W)
Q*DI	# Earth leakage circuit breaker
Q1L	Thermal protector backup heater
R2T	Outlet backup heater thermistor
X*M	Thermistor strip
X*Y	Connector

*: Optional
#: Field supply

Control box option: option box

English	Translation
(1) Connection diagram	(1) Connection diagram
Alarm output	Alarm output
Control box	Control box
Electric pulse meter inputs: 5 V DC pulse detection (voltage supplied by PCB)	Electric pulse meter inputs: 5 V DC pulse detection (voltage supplied by PCB)
Ext. heat source	External heat source
External indoor ambient sensor option	External indoor ambient sensor option
Indoor	Indoor
Max. load	Maximum load
Max. voltage	Maximum voltage
Min. load	Minimum load
Option box	Option box
Power limitation digital inputs: 5 V DC detection (voltage supplied by PCB)	Power limitation digital inputs: 5 V DC detection (voltage supplied by PCB)
Space C/H On/OFF output	Space cooling/heating On/OFF output
(2) Legend	(2) Legend
A4P	Extension PCB (control, optional)

English		Translation
Q*DI	#	Earth leakage circuit breaker
R6T	*	External indoor ambient sensor option
S1P	#	Digital power limitation input 1
S2P	#	Digital power limitation input 2
S3P	#	Digital power limitation input 3
S4P	#	Digital power limitation input 4
S5P-S6P	#	Electrical meters
X*M		Terminal strip
X*Y		Connector
(3) Notes		(3) Notes
X1M		Main terminal
-----		Earth wiring
15		Wire number 15
-----		Field supply
①		Several wiring possibilities
		Option
		Wiring depending on model
		Switch box
		PCB
(4) Option switch box layout		(4) Option switch box layout

*: Optional
#: Field supply

8 Technical data


Electrical connection diagram

Notes:


- In case of signal cable: keep minimum distance to power cables > 5 cm
- Available heaters: see combination table

Typical configuration		
		2 low voltage wires
		Standard: 4 low voltage wires Optional: 4 high voltage wires
		Only for EWYQ* Standard: 4 low voltage wires Optional: 5 high voltage wires Inside: 6 or 7 wires to BUH Valve kit: 3 wires



Power supply




Field supply




Optional part




Standard part



External room thermostat (main zone)





Field supply



4D108909







ERC



Copyright 2017 Daikin

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

4P492492-1B 2018.06